

# Modbus Isolated IO Controller Datasheet



## 1 Introduction

The Modbus Isolated IO Controller provides two isolated channels each for digital and analog inputs. It supports a variety of power source options, enabling signal levels of 3.3V, 5V, 10V, and 12V. Additionally, It can source power from either internal or external voltage supplies for I/O functionality, offering greater flexibility in system integration. Each channel (input and output) is isolated from the others.

Each digital output can switch between 0V and 3.3V, 5V, 12V or referenced to an external voltage source. Each digital input can be between 0V and 1.8V to 12V. A 5V voltage source is provided for common applications that switch between 0-5V.

Each analog output can produce a voltage between 0-10V, and each analog input supports voltage or current controlled input sources ranging between 0-10V.

The controller may be used in numerous and diverse applications such as simple IO control, or 0-10V dimmers, weather station, water level detector or sensor, etc.

## 1.1 Features

- 2 isolated digital output channels
- 2 isolated digital input channels
- 2 isolated analog output channels
- 2 isolated analog input channels
- Built-in power supply (3.3V/ 5V/ 10V/ 12V) and external power supply option
- Flexible combination of internal or external power supply
- Implements Modbus RTU protocol
- Low power consumption
- Operating temperature range: 0°C to +55°C
- Flush mount and DIN Rail mounting options

Visit <https://brtsys.com/resources> for more information.



Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted, or Reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. BRT Systems Pte Ltd (BRTSys) will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device, or System in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. BRT Systems Pte Ltd, 1 Tai Seng Avenue, Tower A, #03-01 Singapore 536464. Singapore Registered Company Number: 202220043R.

## 2 Part Numbers / Ordering Information

| Part Number | Description                    |
|-------------|--------------------------------|
| MC-0601-01A | Modbus Isolated IO Controller  |
| MA-0102-01A | Modbus RS485-RJ11 Cable (30cm) |
| LA-1201-01A | LDSBus DIN Rail Mount Set      |

**Table 1 - Part Numbers / Ordering Information**

## **Table of Contents**

|   |  |           |
|---|--|-----------|
| <b>1</b>  | <b>Introduction .....</b>                                    | <b>1</b>  |
| 1.1   | Features .....   | 1         |
| <b>2</b>  | <b>Part Numbers / Ordering Information .....</b>             | <b>2</b>  |
| <b>3</b>  | <b>Specifications .....</b>                                  | <b>5</b>  |
| <b>4</b>  | <b>FCC Compliance Statement.....</b>                         | <b>6</b>  |
| <b>5</b>  | <b>Hardware Features .....</b>                               | <b>7</b>  |
| <b>6</b>  | <b>Isolated IO Controller Configuration and Installation</b> | <b>9</b>  |
| 6.1   | Connection Diagram for Standard Modbus Power Supply ....     | 9         |
| 6.2   | RS485-RJ11 Cable(30cm) .....                                 | 10        |
| <b>7</b>  | <b>Mounting Instructions .....</b>                           | <b>11</b> |
| 7.1   | Flush Mount.....   | 11        |
| 7.2   | DIN Rail Mount.....  | 11        |
| <b>8</b>  | <b>Terminal Wiring Instructions Isolated IO Controller</b>   | <b>12</b> |
| 8.1   | Isolated IO Digital INPUT Setup.....                         | 13        |
| 8.2   | Isolated IO Digital OUTPUT Setup .....                       | 14        |
| 8.3   | Isolated Analog INPUT Setup .....                            | 15        |
| 8.4   | Isolated Analog OUTPUT Setup .....                           | 16        |
| <b>9</b>  | <b>Modbus Registers .....</b>                                | <b>17</b> |
| <b>10</b>   | <b>Mechanical Dimensions .....</b>                           | <b>20</b> |
| <b>11</b>   | <b>System Status LED Indicators.....</b>                     | <b>21</b> |
| <b>12</b>   | <b>Contact Information .....</b>                             | <b>22</b> |
| <b>Appendix A – References .....</b>                | <b>23</b>  |           |
| Document References .....                           | 23   |           |
| Acronyms and Abbreviations.....                     | 23   |           |
| <b>Appendix B – List of Figures and Tables.....</b> | <b>24</b>  |           |
| List of Figures .....                               | 24   |           |

|  |           |
|--|-----------|
| <b>List of Tables.....</b>                 | <b>24</b> |
| <b>Appendix C – Revision History .....</b> | <b>25</b> |

### 3 Specifications

|                                 |                           |   |
|---------------------------------|---------------------------|---|
| <b>Features</b>                 | Interface                 | RS485 Modbus RTU  |
|                                 | System Status Indicator   | 1x RGB LED  |
|                                 | Mounting                  | Flush Mount<br>DIN-Rail Mount                                 |
| <b>Power</b>                    | Modbus Voltage            | 9-24V DC Bus Power  |
|                                 | Device Input Voltage      | 5V DC   |
|                                 | Power (Typ)               | 1.15W   |
|                                 | Power (Max)               | 1.20W   |
|                                 | Output Power*             | 3.3V/30mW   |
|                                 |                           | 5V/50mW   |
|                                 |                           | 10V/400mW   |
|                                 |                           | 12V/240mW   |
| <b>Analog Input</b>             | Number of Channels        | 2   |
|                                 | Analog Input range        | 0V - 10V  |
|                                 | Analog Input resolution   | 10mV  |
|                                 | Analog Input Accuracy     | Typical: +/- 3%;<br>For 0V - 1V, Accuracy: +/- 10mV (typical) |
| <b>Analog Output</b>            | Number of Channels        | 2   |
|                                 | Analog Output range       | 0V - 10V  |
|                                 | Analog Output resolution  | 10mV  |
|                                 | Analog Output Accuracy    | Typical: +/- 3%;<br>For 0V - 1V, Accuracy: +/- 10mV (typical) |
| <b>Digital IO Input</b>         | Number of Channels        | 2   |
|                                 | Digital Input Voltage     | 1.8VDC - 12VDC (refer to external power voltage)              |
| <b>Digital IO Output</b>        | Number of Channels        | 2   |
|                                 | Digital Output Voltage    | 1.8VDC - 12VDC (refer to external power voltage)              |
| <b>Physical Characteristics</b> | Color                     | White   |
|                                 | Housing                   | Polycarbonate   |
|                                 | Dimension                 | L138.2mm x W76.0mm x H31.9mm                                  |
| <b>Environmental Limits</b>     | Operating Temperature     | 0 to 55°C   |
|                                 | Storage Temperature       | -20 to 85°C   |
|                                 | Ambient Relative Humidity | 5 to 95% (non-condensing)                                     |
| <b>Package Contents</b>         | Device                    | 1x Modbus Isolated IO Controller                              |
|                                 | Wire Assembly             | 1x Modbus RS485-RJ11 Cable(30cm)                              |
| <b>Optional</b>                 | Mounting Accessories      | 1x LDSBus DIN Rail Mount set                                  |

**Table 2 - Modbus Isolated IO Controller Specifications**

\*Total current output up to 60mA.

## 4 FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) These devices may not cause harmful interference, and
- (2) These devices must accept any interference received, including interference that may cause undesired operation.

**NOTE:** The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, at least 20cm of separation distance between the device and the user's body must be always maintained.

### FCC Radiation Exposure Statement


This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with the instructions provided, and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

### Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



## 5 Hardware Features



**Figure 1 - Modbus Isolated IO Controller Hardware Features**

| Function                    | Labels                       | Description  |
|-----------------------------|------------------------------|--|
| 2-CH Digital Input          | IN1+<br>IN1-<br>IN2+<br>IN2- | Two individual digital input channels to measure (monitor) the digital input TTL status. These 2 inputs are isolated from each other.                  |
| 2-CH Digital Output         | OUT2<br>OUT1                 | Two individual digital output channels to control external controller by TTL signal  |
|                             | HV+<br>HV-                   | Used to define the power supply of Digital IO Output.<br>OUT1 and OUT2 share a common power source (on-board external) though HV+ and HV- connections. |
| 2-CH Analog Input           | VIN2<br>VIN1                 | Two individual analog input channels to measure (monitor) the analog voltage. These 2 inputs are isolated from each other.                             |
| 2-CH Analog Output          | VOUT2<br>VOUT1               | Two individual analog output channels to supply the analog voltage<br>VOUT1 and VOUT2 share a common power source (on-board).                          |
| Power Source                | 3V3<br>5V<br>10V<br>12V      | Output supply voltage for internal or external use   |
| System Status LED Indicator | LED                          | Status LED   |
| RJ12 Port                   | Modbus                       | Modbus data and power interface port   |


**Table 3 - Modbus Isolated IO Controller Hardware Features**



## 6 Isolated IO Controller Configuration and Installation

Please visit <https://brtsys.com/resources/software/utility-tools> to access the Modbus Configuration Utility guide on how to configure the device name, device address and termination settings before using it for your specific application.

### 6.1 Connection Diagram for Standard Modbus Power Supply




**Figure 2 - Connection Diagram for Standard Modbus Power Supply**

#### Setup Instructions:

1. Use a Cat5e/Cat6e RJ45 Twisted Pair Cable to connect the Modbus controller (Host) to the network for RS485 communication and power.
2. Connect each Modbus device to the network using either an RS485-JST cable or an RS485-RJ11 cable, as provided with the device.
3. BRTSys Modbus devices have built-in bus termination resistors. These resistors can be enabled or disabled by using the BRTSys [Modbus Configuration Utility](#). When installing the device as the last device on the bus, these terminations may be used to terminate the bus.

## 6.2 RS485-RJ11 Cable(30cm)



**Figure 3 - RS485-RJ11 Cable(30cm)**

| PIN Legend | Function                     |
|------------|------------------------------|
| VIN        | Modbus Input Voltage 9-24VDC |
| GND        | Ground                       |
| GND        | Ground                       |
| B          | RS485-B                      |
| A          | RS485-A                      |

**Table 4 - RS485-RJ11 Cable (30cm) Pin Configuration**

## 7 Mounting Instructions

### 7.1 Flush Mount


The device can be flush mounted directly on a wall or any flat surface using 2 M3.5\*16mm (thread) screws.



**Figure 4 - Modbus Isolated IO Controller Flush Mount**

### 7.2 DIN Rail Mount


The device can be mounted on a DIN Rail using the Modbus DIN Rail Mount set. This set is optional and includes the bracket and mounting screws.



**Figure 5 - Modbus Isolated IO Controller DIN Rail Mount**

## 8 Terminal Wiring Instructions Isolated IO Controller

Terminal blocks are connected with screws. To clamp the wire to the terminal block, insert a 0.4mm x 2.5mm slotted screwdriver and rotate in a clockwise direction. To release the wire, turn the handle in an anticlockwise direction.




**Figure 6 - Clamping wire with screwdriver in Clock-wise Direction**

Table 5 provides a list of American Wire Gauges (AWGs) that can be used in Terminal Blocks.

| Conductor Type                             | Wire diameter/AWG                 |
|--|-----------------------------------|
| Solid conductor                            | 0.2~1.5mm <sup>2</sup> /26~16 AWG |
| Stranded conductor                         | 0.2~1.5mm <sup>2</sup> /26~16 AWG |
| Stranded conductor; with insulated ferrule | 0.25~0.75mm <sup>2</sup>          |

**Table 5 - AWG to use in terminal block**

As shown in Figure 7, the wire strip is 3mm to 5mm long.




**Figure 7 - Wire Strip Length**

## 8.1 Isolated IO Digital INPUT Setup

The 2CH isolated digital input supports external digital signals ranging from 1.8 to 12V. The two options for connecting are as follows:

**Note:** As each channel is independent, Channel 1 and Channel 2 can use different configurations.

### IO Digital Input with 5V Application



Use AWG 26~16; The RED wire indicates that it comes from an external IO source

→ Connect to the IN1- or IN2-



Use AWG 26~16; The BLACK wire indicates that it comes from external GND


→ Connect to the GND



Use AWG 26~16; The BLUE wire connects to the 5V source on board

→ Connect to the IN1+ or IN2+

### IO Digital Input with External Pull-up



Use AWG 26~16; The RED wire indicates that it comes from External IO source

→ Connect to the IN1+ or IN2+



Use AWG 26~16; The BLACK wire indicates that it comes from external GND


→ Connect to the IN1- or IN2-




**WARNING:** When wiring, always TURN OFF the Power Supply.

## 8.2 Isolated IO Digital OUTPUT Setup


The 2CH isolated digital output supports external digital signals ranging from 1.8 to 12V. The two options for connecting are as follows:




### Digital Output with 5V Application



-  Use AWG 26~16; The RED wire indicates that it outputs an IO signal  
→ Connect to the OUT1 or OUT2
-  Use AWG 26~16; The BLACK wire connects to on board GND  
→ Connect to HV-
-  Use AWG 26~16; The Blue wire connects to the 5V source on board  
→ Connect to the HV+

### Digital Output with External Source




-  Use AWG 26~16; The RED wire indicates that it outputs IO signal  
→ Connect to the OUT1 or OUT2
-  Use AWG 26~16; The BLACK wire indicates that it comes from External GND  
→ Connect to HV-
-  Use AWG 26~16; The BLUE wire indicates that it comes from External Source  
→ Connect to HV+

### 8.3 Isolated Analog INPUT Setup

The 2CH isolated analog input supports external analog signals ranging from 0 to 10V. The two options for connecting are as follows:

#### Analog Input with External Voltage Source




Use AWG 26~16; The RED wire indicates that it comes from external voltage source  
 → Connect to VIN1 or VIN2



Use AWG 26~16; The BLACK wire indicates that it comes external GND  
 → Connect to GND

#### Analog Input with External Current Source



Use AWG 26~16; The RED wire indicates that it comes from external current source  
 → Connect to VIN1 or VIN2



Use AWG 26~16; The BLACK wire indicates that it comes from external GND  
 → Connect to GND




Serial Resistor value depends on current source  
 → Connect in between VIN1/VIN2 and GND

For example: Application current source 4mA to 20mA, recommend using 450ohm resistor

## 8.4 Isolated Analog OUTPUT Setup

The 2CH isolated analog output supports external analog signals ranging from 0 to 10V. The two options for connecting are as follows:

### Analog Voltage Output



Use AWG 26~16; The RED wire indicates that it outputs 0V - 10V power

→ Connect to VOUT1 or VOUT2



Use AWG 26~16; The BLACK wire indicates that it comes external GND

→ Connect to GND



## 9 Modbus Registers

| Parameter                                 | Starting Address | Quantity of Registers | Supported Function Code | Parameter Range and Description  | Default                       |
|---|------------------|-----------------------|-------------------------|--|-------------------------------|
| <b>Address<sup>(1)</sup></b>              | 0000H            | 1                     | 0x03/0x10               | 1 to 126   | 126                           |
| <b>RS485 Termination<sup>(1)</sup></b>    | 0001H            | 1                     | 0x03/0x10               | 0 - Termination Off<br>1 - Termination On  | 0<br>(Off)                    |
| <b>Baud Rate<sup>(1)</sup></b>            | 0002H            | 1                     | 0x03/0x10               | 0 - 1200 bps<br>1 - 2400 bps<br>2 - 4800 bps<br>3 - 9600 bps<br>4 - 19200 bps<br>5 - 38400 bps<br>6 - 115200 bps | 9600 bps                      |
| <b>Parity<sup>(1)</sup></b>               | 0003H            | 1                     | 0x03/0x10               | 0 - None<br>1 - Odd<br>2 - Even  | Even                          |
| <b>Status LED Enable<sup>(1)</sup></b>    | 0004H            | 1                     | 0x03/0x10               | 0 - LED Off<br>1 - LED On  | 1<br>(LED On)                 |
| <b>Reserved</b>                           | 0005H            | 1                     | N/A                     | N/A  | N/A                           |
| <b>REG_DO_CHANNEL_NO</b>                  | 0006H            | 1                     | 0x03/0x10               | Digital Channel number X=0 refers to Channel 1; X=1 refers to Channel 2  | 0<br>(Channel 1)              |
| <b>REG_DO_CHANNEL_CONTROL</b>             | 0007H            | 1                     | 0x03/0x10               | Channel x control<br>0 - Deactivate<br>1 - Activate  | 0x00FF<br>(No Action)         |
| <b>REG_DO_CHANNEL_MODE</b>                | 0008H            | 1                     | 0x03/0x10               | Channel x mode<br>0 - Level Mode<br>1 - Pulse Mode<br>3 - Sequence Mode  | 0x0000 (Level Mode)           |
| <b>REG_DO_CHANNEL_START_STOP_POLARITY</b> | 0009H            | 1                     | 0x03/0x10               | Start/stop polarity for Channel x<br>polarity_negative = 0, polarity_positive = 1                                | 0x0001<br>(Positive Polarity) |
| <b>REG_DO_CHANNEL_DEACTIVATION_MODE</b>   | 000AH            | 1                     | 0x03/0x10               | Deactivation mode for Channel x<br>0 - Deactivation None<br>1 - Immediate<br>2 - Immediate After T1              | 0x0000<br>(Deactivation None) |
| <b>REG_DO_CHANNEL_NO_OF_CYCLES</b>        | 000BH            | 1                     | 0x03/0x10               | Number of cycles for Channel x (1 - 65535)   | 1                             |
| <b>REG_DO_CHANNEL_NO_OF_PAIRS</b>         | 000CH            | 1                     | 0x03/0x10               | Number of pairs for Channel x (1 - 255)  | 1                             |
| <b>REG_DO_CHANNEL_T1</b>                  | 000DH            | 1                     | 0x03/0x10               | Digital out pulse/sequence 0 T1 Time<br>(0 to 65535 Secs)  | 0x0000<br>(0 Sec)             |
| <b>REG_DO_CHANNEL_T2</b>                  | 000EH            | 1                     | 0x03/0x10               | Digital out pulse/sequence 0 T2 Time<br>(0 to 65535 Secs)  | 0x0000<br>(0 Sec)             |
| <b>REG_DO_CHANNEL_S1T1</b>                | 000FH            | 1                     | 0x03/0x10               | Digital out sequence 1 T1 Time<br>(0 to 65535 Secs)  | 0x0000<br>(0 Sec)             |
| <b>REG_DO_CHANNEL_S1T2</b>                | 0010H            | 1                     | 0x03/0x10               | Digital out sequence 1 T2 Time   | 0x0000                        |


|                                    |       |     |           |  |                |
|------------------------------------|-------|-----|-----------|--|----------------|
|                                    |       |     |           | (0 to 65535 Secs)  | (0 Sec)        |
| <b>REG_DO_CHANNEL_S2T1</b>         | 0011H | 1   | 0x03/0x10 | Digital out sequence 2 T1 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S2T2</b>         | 0012H | 1   | 0x03/0x10 | Digital out sequence 2 T2 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S3T1</b>         | 0013H | 1   | 0x03/0x10 | Digital out sequence 3 T1 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S3T2</b>         | 0014H | 1   | 0x03/0x10 | Digital out sequence 3 T2 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S4T1</b>         | 0015H | 1   | 0x03/0x10 | Digital out sequence 4 T1 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S4T2</b>         | 0016H | 1   | 0x03/0x10 | Digital out sequence 4 T2 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S5T1</b>         | 0017H | 1   | 0x03/0x10 | Digital out sequence 5 T1 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S5T2</b>         | 0018H | 1   | 0x03/0x10 | Digital out sequence 5 T2 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S6T1</b>         | 0019H | 1   | 0x03/0x10 | Digital out sequence 6 T1 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S6T2</b>         | 001AH | 1   | 0x03/0x10 | Digital out sequence 6 T2 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S7T1</b>         | 001BH | 1   | 0x03/0x10 | Digital out sequence 7 T1 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>REG_DO_CHANNEL_S7T2</b>         | 001CH | 1   | 0x03/0x10 | Digital out sequence 7 T2 Time (0 to 65535 Secs)                           | 0x0000 (0 Sec) |
| <b>RESERVED</b>                    | 001DH | 1   | N/A       | N/A  | N/A            |
| <b>REG_AO_CHANNEL1_SET_VOLTAGE</b> | 001EH | 1   | 0x03/0x10 | 0 - 10000 millivolt  | 0 mV           |
| <b>RESERVED</b>                    | 001FH | 1   | N/A       | N/A  | N/A            |
| <b>REG_AO_CHANNEL2_SET_VOLTAGE</b> | 0020H | 1   | 0x03/0x10 | 0 - 10000 millivolt  | 0 mV           |
| <b>Device UUID</b>                 | 0026H | 8   | 0x03      | MCxxxxxxxxxxxxyy where x is ASCII character and yy is 16bit running number | N/A            |
| <b>Device Firmware Version</b>     | 002EH | 1   | 0x03      | Corresponding to version number  | N/A            |
| <b>Device Part Number</b>          | 002FH | 1   | 0x03      | Device ID  | 0xC001         |
| <b>Reserved</b>                    | 0030H | N/A | N/A       | N/A  | N/A            |
| <b>RELAY DI_CHANNEL_1_STAT US</b>  | 0031H | 1   | 0x03      | Digital channel 1  | N/A            |
| <b>RELAY DI_CHANNEL_2_STAT US</b>  | 0032H | 1   | 0x03      | Digital channel 2  | N/A            |
| <b>RELAY AI_CHANNEL_1_VAL</b>      | 0033H | 1   | 0x03      | Voltage level in channel 1   | N/A            |
| <b>RELAY AI_CHANNEL_2_VAL</b>      | 0034H | 1   | 0x03      | Voltage level in channel 2   | N/A            |
| <b>Reset</b>                       | 0150H | 1   | 0x06      | Write 1 to reset   | N/A            |
| <b>Reserved</b>                    | 0152H | N/A | N/A       | N/A  | N/A            |
| <b>Identify</b>                    | 0154H | 1   | 0x06      | Write 1 to start blinking the device                                       | N/A            |

|  |  |  |  |                        |  |
|--|--|--|--|------------------------|--|
|  |  |  |  | @1Hz for 10<br>seconds |  |
|--|--|--|--|------------------------|--|


**Table 6 - Modbus Registers**

<sup>(1)</sup>This indicates that any updates to these communication/status register(s) will only take effect after the device has been rebooted.


## 10 Mechanical Dimensions



**Figure 8 - Modbus Isolated IO Controller Dimension – Top View**







**Figure 9 – Modbus Isolated IO Controller Dimension – Side View**



**Figure 10 – Modbus Isolated IO Controller Dimension – Bottom View**

**Note:** All dimensions are in millimetres.

## 11 System Status LED Indicators

| Device Status              | LED Color                 |   | Flashing Frequency        | Description                |
|----------------------------|---------------------------|---|---------------------------|----------------------------|
| Termination ON             | BLUE                      |  | Steady – Non- flashing    |                            |
| Termination OFF            | GREEN                     |  | Steady – Non- flashing    |                            |
| Device Configuration Error | RED                       |  | Steady – Non- flashing    | Device configuration error |
| Communication              | RED/GREEN/<br>BLUE/YELLOW | -   | Blink twice (Short blink) | Device in communication    |
| Firmware update            | YELLOW                    |  | Steady – Non- flashing    | Device firmware update     |

**Table 7 - System Status LED Indicators**

### **Notes:**

1. For reliable communication, ensure that the power supply and the RS485 termination settings are correct.
2. Ensure that the Modbus address and baud rate are configured correctly before deployment.

## 12 Contact Information

Refer to <https://brtsys.com/contact-us/> for contact information.

System and equipment manufacturers and designers are responsible to ensure that their systems, and any BRT Systems Pte Ltd (BRTSys) devices incorporated in their systems, meet all applicable safety, regulatory and system-level performance requirements. All application-related information in this document (including application descriptions, suggested BRTSys devices and other materials) is provided for reference only. While BRTSys has taken care to assure it is accurate, this information is subject to customer confirmation, and BRTSys disclaims all liability for system designs and for any applications assistance provided by BRTSys. Use of BRTSys devices in life support and/or safety applications is entirely at the user's risk, and the user agrees to defend, indemnify, and hold harmless BRTSys from any and all damages, claims, suits, or expense resulting from such use. This document is subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document. Neither the whole nor any part of the information contained in, or the product described in this document, may be adapted, or reproduced in any material or electronic form without the prior written consent of the copyright holder. BRT Systems Pte Ltd, 1 Tai Seng Avenue, Tower A, #03-01, Singapore 536464. Singapore Registered Company Number: 202220043R.

## Appendix A – References

### Document References

[Modbus Configuration Utility User Guide](#)

[Modbus Device Configuration Application Note](#)

### Acronyms and Abbreviations

| Terms | Description          |
|-------|----------------------|
| AC    | Alternating Current  |
| AWG   | American Wire Gauges |
| DC    | Direct Current       |
| IoT   | Internet of Things   |
| LED   | Light Emitting Diode |

## **Appendix B – List of Figures and Tables**

### **List of Figures**

|   |    |
|---|----|
| Figure 1 - Modbus Isolated IO Controller Hardware Features .....        | 7  |
| Figure 2 - Connection Diagram for Standard Modbus Power Supply .....    | 9  |
| Figure 3 - RS485-RJ11 Cable(30cm).....                                  | 10 |
| Figure 4 - Modbus Isolated IO Controller Flush Mount.....               | 11 |
| Figure 5 - Modbus Isolated IO Controller DIN Rail Mount.....            | 11 |
| Figure 6 - Clamping wire with screwdriver in Clock-wise Direction ..... | 12 |
| Figure 7 - Wire Strip Length .....                                      | 12 |
| Figure 8 - Modbus Isolated IO Controller Dimension – Top View.....      | 20 |
| Figure 9 – Modbus Isolated IO Controller Dimension – Side View .....    | 20 |
| Figure 10 – Modbus Isolated IO Controller Dimension – Bottom View ..... | 20 |

### **List of Tables**

|   |    |
|---|----|
| Table 1 - Part Numbers / Ordering Information .....             | 2  |
| Table 2 - Modbus Isolated IO Controller Specifications .....    | 5  |
| Table 3 - Modbus Isolated IO Controller Hardware Features ..... | 8  |
| Table 4 - RS485-RJ11 Cable (30cm) Pin Configuration .....       | 10 |
| Table 5 - AWG to use in terminal block .....                    | 12 |
| Table 6 - Modbus Registers .....                                | 19 |
| Table 7 - System Status LED Indicators .....                    | 21 |



## Appendix C – Revision History

Document Title: Modbus Isolated IO Controller Datasheet

Document Reference No.: BRTSYS\_000190

Clearance No.: BRTSYS#122

Product Page: <https://brtsys.com/product-category/actuators/>

Document Feedback: [Send Feedback](#)

| Revision    | Changes         | Date       |
|-------------|-----------------|------------|
| Version 1.0 | Initial Release | 31-07-2025 |